

Scriber

The scriber functionality makes use of the following global variables:

Variable number	Variable name	Description
5785	GVAR_SCRIBER_HEIGHT	Marking height
5786	GVAR_SCRIBER_OFFSET	Difference between plasma torch height and scriber position. The final scriber position is taken as gvariables 5785 + 5786
5787	GVAR_SCRIBER_LIFT	Lift height after marking
5788	GVAR_SCRIBER_POSX	Coordinate X
5789	GVAR_SCRIBER_POSY	Coordinate Y

The posX and posY values represent the coordinates at which the last IHC measurement was made. If the new coordinate for marking differs from this point by less than the specified distance, then it is assumed that no additional probing is necessary and the marking procedure is started. If the distance from the original IHC measurement position differs by more than a specified distance however, then the probing is done again (via the M72 command).

This method works well for work material (such as a metal sheet for plasma cutting) that may be slightly uneven or crooked. For spring-loaded scribes, changing the height within a small range does not impact the overall performance by a significant margin, therefore it is not necessary to always run a probing process prior to marking.

From:

<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:

<http://docs.pv-automation.com/mycnc/scriber>

Last update: **2021/12/21 12:22**

